



Cordless handset (DECT)

Welcome to swissvoice

Thanks for choosing ePure HD.

The ePure HD handset is aimed to be used with a CAT-iq 2.0 base station or gateway to ensure full functionality. Registered to a GAP or CAT-iq 1.0 base, the handset supports incoming and outgoing external calls, and features a local phonebook and a local call list to ensure proper functionality.

The ePure HD offers excellent voice quality, including HD Voice calls. The HD Voice sound quality is richer, more dynamic, and offers a better listening experience. Now callers can feel closer to each other.

Setting your handset

Contents of the package

- 1 handset
- 1 charging station
- 1 power supply MN-A002-A080, 7.5 V \equiv , 300mA from MEIC
- 1 rechargeable battery Li-Ion 3.7 V / 550 mAh


1- Make sure the base station is ready

To register your handset you must install a base station or gateway first!

Check in your base station user manual, how to register a DECT handset, and open the registration mode.

2- Insert the battery

Install the battery pack the right way in the handset battery compartment: position the 3 metal contacts of the battery pack against the 3 blade contacts.



Green dots

Place the cover: align the green dot on the handset with the one on the cover. Align the cover top against the handset top, then press until middle and bottom sides click into place


3- Select the language

Press \updownarrow to scroll to the desired language. Confirm with OK.




4- Installation assistant

The handset is starting the installation process to register the handset. Press OK when ready.



5- Select the base

Choose your gateway or base in the compatibility list displayed. If your base does not appear in the list, select OTHER BASE. Confirm by OK.



6- Register the handset


The handset is starting the registration process. In case the base does not use 0000 as a system pin code, the handset will request the pin.



Make sure the base station is in registration mode (see the base user manual).

7- Finalize the installation

After successful registration the handset is automatically assigned a name (e.g. DECT 1, INT 1 or Handset 1).




If you have registered to a base where the time can not be synchronised, the handset will ask you to setup the time.



If you have more than one IP line: you can select the line(s) the handset will ring for and the default outgoing line.

8- Connect the charger



Main power socket

Insert the plug into the corresponding socket on the charger. Then insert the power supply in the 230 V socket.

9- Congratulations ! You have now set up your ePure HD.

For proper operation of the handset the battery must be fully charged initially. The battery will take around 4 hours to fully charge.

User manuals

For complete operating instructions about your new ePure HD, please download the user manual from our website :
<http://product.swissvoice.net/en/epure-hd>

Troubleshooting

Start the installation process again if you fail to register your ePure HD with the base station. Press «OK».

«Our contacts», and shared call lists are CAT-iq 2.0 functions not available with GAP bases; when registered to a GAP base, «My contacts» and local call lists are available.

Fulleco/NEMO (non-emission mode), SUOTA, HD Voice and Repeater features must also be supported and enabled by the base station in order to work with the ePure HD handset.

Your ePure-HD Fulleco functionality is based on the DECT CAT-iq 2.0 NEMO standard. Some base stations are using non-emission modes not compatible with the DECT NEMO standard. If the handset is loosing lock in idle or is not ringing when some incoming calls are presented to the base, please disable the non-emission mode on the base.

Some functionalities may be available or not from base to base, please refer to our website for more information.

Some functionalities may not be available depending on your network operator.

Support

If you have any questions about products, please visit our FAQ on:

www.swissvoice-faq.net


In case you need additional help, please contact Swissvoice Customer Service either through :

www.swissvoice.net/contact or
on freephone number 00 800 10 18 10 10.

Warranty conditions

Your telephone is subject to a guarantee from the date of purchase in accordance with the legal provisions of the country in which the telephone was purchased. As evidence of the date of purchase, please keep the receipt or the warranty card completed by the retailer. All defects attributable to material and manufacturing faults will be corrected free of charge within the warranty period, either by repairing or replacing the defective equipment. The warranty does not cover expendable materials (battery cells), defects which affect the value or use of the equipment only insignificantly, and damage caused by incorrect use, ordinary wear and tear, or manipulation by third parties. This warranty does not cover consequential damage caused by the use, failure or defectiveness of the product. In particular, no liability whatsoever is accepted for damage to property and pecuniary loss. To claim under this warranty, please contact the retailer where you purchased your telephone.

Main Menu icons



Handset icons

- Coverage symbol**
Shows reception when the handset is within range of the base station. Flashes red when out of range or not registered with the base station. Lit blue, when the electromagnetic radiation between the base station and the handset is shut down (Fulleco activated).
- Alarm set**
Indicates that the alarm is set.
- Handsfree on**
Indicates that handsfree speaking is activated.
- Ringer off**
Indicates that the ringer is switched off.
- Keypad lock**
Indicates that the keypad is locked.
- Battery full**
Indicates that the battery is charged.
- Battery empty**
Indicates that the battery is discharged.
- Missed calls**
Displayed if you have missed calls in the calls list.
- You have messages on your voicebox***
Displayed if you have new messages on your network answer machine.

LED indicator

Your ePure HD handset has a LED indicator which is flashing on some events, indicating:

- You are receiving an internal or external call.
- You have one or more missed calls.
- You have one or more voice mails pending.
- You are receiving a software update.

Contacts and call list icons


- Symbols displayed in the contact and call lists:
- Missed calls
 - Home number
 - Answered calls
 - Mobile number
 - Dialled calls
 - Office number

Handset keys




Quick access

In idle, the navigation key allows quick access to important functions.



Volume

During calls, the navigation key can be used to increase earpiece or handsfree volume.



Call lists

Missed, answered and dialled calls are saved in the calls lists.

If you have received new missed calls, the LED indicator flashes and the symbol appears in the display.

Dialling a number from the calls list: Press . Select MISSED CALLS, ANSWERED CALLS, DIALLED CALLS or ALL CALLS, press OK to confirm. Scroll through the relevant calls list using until you reach the entry you are seeking. Press to dial the selected number.

Pressing the green key when handset is in standby opens the All calls list (if available) or goes off hook.

My/Our contacts

Your ePure HD handset gives you access to 2 phonebooks:

- Our contacts: your contacts are saved on the base station or gateway. All the handsets registered to the base can access these shared contacts.
- My contacts: your contacts are saved locally on the handset.

By default, the ePure HD is using the phonebook "Our contacts".

Press the softkey under CONTACTS or press to open the contacts. Select the number you want to call and press to call the number.

You can easily switch between phonebooks: Open the contacts. Press the softkey under OPTIONS. Select OUR CONTACTS or MY CONTACTS.

New contacts can be created from the contacts, press OPTIONS, then NEW CONTACT, or from the call lists, press OPTIONS, then SAVE NUMBER.

Voicebox*

You can edit the network answer machine access number in the submenu VOICEBOX, VOICEBOX NUMBER. To access new messages, press and hold down for around 2 seconds to automatically dial the access number of your network answer machine.

*check with your operator whether this network function is available.

Safety precautions

- Caution: Warning/danger statement, follow safety precautions!**
- ⚡ Please note that the ringer for incoming calls as well as signal tones are emitted on the handset loudspeaker. Do not therefore hold the handset close to your ear while one of these functions is on, otherwise your hearing may be affected.
 - 🌡 The ambient temperature must be between 5°C and 40°C.
 - 🔌 Use only the supplied power supply: MN-A002-A080; 7.5 V, 300mA from MEIC
 - ⚡ This product requires an electrical supply of 100-240 volts AC.
 - 🔌 The mains power plug must always be easily accessible.
 - 🔌 To disconnect the device from mains, separate the plug from the wall socket first.

Rechargeable battery
Use only the supplied rechargeable battery: Waitley 043048, Li-Ion 3.7 V - 550 mAh, Swissvoice 20405855. Using other rechargeable batteries or non-rechargeable batteries/primary cells can be dangerous and cause malfunctions in or damage to the telephone.

- Please note:
- ⚡ Do not immerse batteries in water or throw in the fire.
 - 🔌 Rechargeable batteries can become warm while recharging. This is normal and not dangerous.
 - ⚡ Do not use any other type of charging unit since this may damage the batteries.
 - 👂 Before using the telephone, wearers of hearing aids should note that radio signals can be picked up by the hearing aid and cause an unpleasant buzzing noise.
 - 💣 Do not use your cordless telephone in environments at risk from explosion (e.g. paintworks, petrol stations etc.)
 - 🚿 Do not position the telephone in bathrooms or showers.
 - 🏥 The radio signals may influence the working of medical equipment.
 - 🔌 In the event of a power cut or if the battery is discharged, your cordless telephone will not function!
 - 🔌 The handset must not be charged up without battery or the battery cover in place.
 - ⚡ Do not touch open contacts!

Please dispose the rechargeable battery according to the official regulations.

The telephone must not be disposed of in normal domestic waste. Please take it to a collection point for processing electrical and electronic equipment.

The CE symbol confirms the conformity of the handset and charging bay with the EU Directive 99/5/EC on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity. The declaration of conformity may be viewed at: www.swissvoice.net